



Nintendo DSi Battery Replacement

Replace the battery in your Nintendo DSi.

Written By: Walter Galan



INTRODUCTION

Replacing your DSi's battery only requires a Phillips #00 screwdriver and a thin prying tool.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Nintendo DSi Battery](#) (1)

Step 1 — Battery



- Unscrew the two Phillips screws securing the battery cover to the lower case.
- ⓘ The screws remain captive to the battery cover.
- Grasp the battery cover and lift out of the lower case.

Step 2



- Wedge the edge of a spudger in between the top of the battery and its lower case housing and pry upwards to dislodge the battery.
- Grasp the battery and remove it from the DSi.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 01:48:50 PM.